



Plymasters

Fixing Recommendations for Unfinished Plywood

Plymasters has partnered with Soudal to provide the best recommendations for fixing our panels to timber framing/battens and uncoated timber walls.



Plymasters Panels

- Marine Gaboon BB/CC
- Keruing Brownwood
- Meranti
- NZ Pine

Soudal Glue Recommendations

- Gorilla Grip 2 Hr Cure
- Gorilla Grip 1 Hr Cure

Preparation

Lightly dampen the surface with water to improve adhesive bond.

Ensure that walls/ framing/ battens are straight and level.

Application

20mm blobs of Gorilla Grip every 500mm down every framing stud or batten.

Fixing

Mechanically fix in place with appropriate panel pins.

